



制 造 商：童音母嬰用品（上海）有限公司
地 址：上海市嘉定區順達路938號2幢3層325室、326室、327室
生產企業：昆山倍凱斯兒童用品有限公司
地 址：江蘇省昆山市周市鎮富強路7號3號房
電 話：400-008-0996
郵 箱：philips.avent@ibabybell.com
網 址：www.philips.com/avent

PHILIPS


AVENT

PORTO PRO (波特PRO)

兒童推車 使用說明書

適合于0-3歲兒童

執行標準：GB/T 14748-2025



使用前請仔細閱讀說明書，並妥善保管以備日後查閱

目錄

警告	02
維修和保養	03
產品組件	04
部件名稱	05
車台的展開及安裝	06
前扶手的安裝與拆卸	10
頂蓬的安裝、拆卸與調節	11
五點式安全帶的使用與調節	12
車台的收合	13
車台的展開	14
腳靠的調節	15
頂蓬高度的調節	15
技術支持	15

警告

使用前請仔細閱讀說明書且請妥善保存供日後參考。

- 如果不按照本說明書操作，可能會影響兒童的安全。
- 警告：當兒童乘坐時，看護人不要離開。
- 本推車適用於0-36個月的兒童使用（最大承載體重為22Kg）。
- 警告：使用推車前確保所有鎖定裝置都已處於鎖定狀態。
- 當嬰兒坐在車內時，請勿折疊嬰兒車。
- 警告：兒童乘坐時必須使用安全帶。
- 不要讓嬰兒車在斜坡上無人看管。
- 本產品不適合在奔跑或滑行時使用。
- 警告：在把手上放置任何負載會影響車輛的穩定性。
- 當兒童在嬰兒車中時，請勿拆卸或調整嬰兒車的任何部件。
- 請保持塑料袋遠離嬰兒車，以防止嬰兒窒息。
- 警告：臥兜內不應增加厚度超過20mm的棉墊。
- 座椅下方的置物籃最大負載為2.5千克。
- 禁止使用非生產商提供的附件。

維修和保養

- 定期檢查推車的零件是否鬆動、丟失、損壞或有其他任何部分損傷。根據實際情況如有必要，請安排更換或維修。
- 嬰兒手推車應遠離火源或高溫發熱體。
- 本推車布套不能漂白，不能翻轉幹燥，不能熨燙，不能幹洗。
- 請使用中性肥皂水配合軟布清洗布套、金屬、皮革和塑料表面，輕輕擦拭嬰兒車。擦拭過程中不要使用強刺激或腐蝕性化學液體（如任何清潔劑、溶劑或藥性很強的肥皂）。擦拭後自然晾幹，本嬰兒車布套不可直接放入水中清洗。特殊部位除外。
- 請勿拆卸頂蓬進行洗滌。請勿拆卸、移動或改變嬰兒手推車的布套或五點式安全帶的任何結構部件。請勿在布套、五點式安全帶上添加任何潤滑劑或其它化學物品。

特殊部位清洗說明

- 護肩套和睡籃棉墊外套可拆下單獨清洗。在清洗時請在水溫40度以下手洗，平鋪晾幹。請勿熨燙、幹洗，請勿在陽光下暴曬。


產品組件

部件名稱


產品圖片僅供參考




A




Bx2




Cx2




D



E




F



G

A. 嬰兒推車框架 B. 後輪 C. 前輪 D. 坐兜
E. 扶手 F. 遮陽篷 G. 儲物籃



01 遮陽棚	05 腳靠	09 推把手
02 前扶手	06 前車輪	10 剎車裝置
03 前扶手接口	07 後車輪	11 置物籃
04 肩護套	08 收車按鈕	12 收車鎖定鉤

車台的展開及安裝




圖1：展開車架

1. 打開鎖鉤1，打開前車架，然後按箭頭所示方向推動車把。

車台的展開及安裝




圖1：安裝前輪

1. 推入車輪，直到聽到輕微的“喀哒”聲為止。

圖1：安裝後輪

1. 推入車輪，直到聽到輕微的“喀哒”聲為止。

圖2：拆卸後輪

1. 向下按動按鈕（1）。
2. 拉動車輪（2）。

圖3：車把高度調節

1. 按下按鈕A。 2. 根據需要向前或向後推。

車台的展開及安裝

4




圖4：剎車系統

1. 按下（1），剎車啓用。
2. 按下（2），剎車松開。

5




圖5-A：安裝座椅

1. 將座椅推入，直到聽到輕柔的“喀哒”聲。
2. 確認安裝成功。




圖5-B：取下座椅

1. 抓住座椅並按下按鈕。
2. 垂直拉出座椅（如箭頭所示）。

車台的展開及安裝



圖5-C安裝座椅

1. 推入座椅，直到聽到輕柔的“喀哒”聲為止。
2. 確認安裝成功。




圖5-D：拆卸座椅

1. 托住座椅並按下按鈕。
2. 垂直拉出座椅（如箭頭所示）。

6





圖6：調整座椅傾斜角度


座椅有多個傾斜位置，適合從出生到15公斤（約3歲）。

前扶手的安裝與拆卸

7 扶手安裝



8 扶手拆除



頂篷的安裝、拆卸與調節

9




圖9：準備座位

1. 拉動角度調節裝置來打開座椅（1）。
2. 安裝遮陽篷（2）。
3. 安裝扶手（直到聽到輕輕的咔塔聲）。
4. 展開遮陽篷。

10




圖10：調整座椅傾斜角度

1. 輕輕拉動位于座椅靠背上的角度調節裝置(A)。
2. 將座椅位置調整到所需位置。

11




圖11：遮陽篷調整

1. 展開遮陽篷。

12




圖12：遮陽篷展開

1. 展開型頂篷可保護嬰兒免受紫外線，風的侵害，並提供更舒適的環境。

五點式安全帶的使用與調節

13




圖13-A: 汽車座椅五點式安全帶的安裝

1. 將安全帶上的兩個插片合在壹起（1）。
2. 將兩個插片同時插入“卡扣（2）”上。
3. 往下按，直到聽到輕柔的“喀嗒”聲。
4. 確保安全安裝。




圖13-B: 安全座椅五點式安全帶的拆卸

1. 同時按下卡扣兩側的按鈕。
2. 如圖B所示，拉動五點式安全帶（2）的上部。




圖13-C-安全帶長度調節

1. 按住安全帶扣，調節安全帶。
2. 調整到所需位置。

14




圖14-1: 收車（步驟1）

1. 收起遮陽篷。



圖14-2: 收車（步驟2）

2. 將座椅向前推進。




圖14-3: 收車（步驟3）

3. 將推把向前折疊收起。




圖14-4: 收車（步驟4）

4. 沿著拉手向上提起。




圖14-5: 收車（步驟5）

5. 提起同時，推把自動落下。




圖14-6: 收車（步驟6）

6. 完成整車收合。

車台的展開




圖15: 打開嬰兒推車

1. 打開推車鎖鉤。
2. 擡起把手使其展開。
3. 將把手拉到筆直的位置。




圖15: 打開嬰兒推車

4. 向後打開把手。
5. 打開座椅並將靠背調整到所需位置。
6. 打開遮陽篷。

注意! 使用前, 請確保所有部件均安全正確地安裝, 並且所有鎖定部件均已正確接合。

腳靠的調節




圖16.調整腳靠

1. 按住按鈕 (2)。
2. 調整到所需位置。

頂篷的高度調節




圖17: 調節頂篷的高度

1. 拉住頂篷向上提起, 可將頂棚高度調節。
2. 下拉則可將頂篷高度調節至低檔位。

· 详情请登录 www.philips.com/avent

技術支持



Manufacturer and seller: Babybell Maternal & Child Supplies (Shanghai) Co.,Ltd.
Address: Rooms 325, 326, and 327, 3rd floor, Building 2, No. 938 Shunda Road, Jiading District, Shanghai
Telephone: 400-008-0996
Email: philips.avent@ibabybell.com

PHILIPS

AVENT

PORTO PRO

Baby Stroller User manual

Suitable for
0-3 Years



Please read the manual carefully before use,
and keep it in a safe place for future reference.

Contents

WARNING	02
Maintenance	03
Product components	04
Part name	05
Unfolding and installation of stroller.....	06
Installation and removal of the front armrest	10
Installation, removal and adjustment of the canopy	11
The use and adjustment of the five-point safety belt	12
Folding of the stroller.....	13
Unfolding stroller.....	14
Footrest adjustment	15
Adjust canopy height	15
Technical Support	15

Philips, Avent and the Philips Shield Emblem are registered trademarks of Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Babybell Maternal & Child Supplies (Shanghai) Co., Ltd., and Babybell Maternal & Child Supplies (Shanghai) Co., Ltd. is the warrantor in relation to this product.

© 2026 Babybell Maternal & Child Supplies (Shanghai) Co.,Ltd. All rights reserved.

WARNING

- **Please read the following instructions carefully and keep it with you for reference.**
- Not following the instructions could compromise the baby's safety.
- The baby stroller must be watched by the person in charge at all times.
- The stroller is suitable for Child 0-36 months , and the maximum load-bearing weight is 22Kg .
- Please make sure that the brake is locked before using the baby stroller.
- Please don't fold the baby stroller while the baby is sitting in the stroller.
- Make sure that the baby is wearing the safety belt when sitting in the seat.
- Don't leave the stroller unattended on a slope.
- This product is not suitable for running or sliding.
- Please don't put shopping bags or other heavy items on the baby stroller's handle to prevent the stroller from falling over.
- Please don't disassemble or adjust any of the stroller's parts while the baby is in the baby stroller.
- Please keep plastic bags away from the baby stroller to prevent the baby from suffocating.
- Please don't use a thick cotton blanket more than 20 mm for the bassinet.
- The storage basket under the seat has a maximum carrying capacity of 2.5 kg.
- The use of accessories not provided by the manufacturer is prohibited.
- Regularly check whether the parts of the stroller are loose, missing, damaged. If necessary, please arrange replacement or maintenance according to the actual situation.

Maintenance

- The stroller should be kept away from fire sources or high-temperature heating objects.
- The cloth cover of this stroller cannot be bleached, tumble dried, ironed, or dry cleaned. Please use neutral soapy water and a soft cloth to clean the cloth cover, metal, leather and plastic surfaces.
- Please wipe the stroller gently. Do not use strong irritating or corrosive chemical liquids (such as any detergent, solvent or very strong soap) during the wiping process. Let dry after wiping. The stroller cloth cover cannot be washed directly in the water except for special parts.
- Do not disassemble the canopy for washing. Do not disassemble, move or change the cloth cover of the stroller or any structural parts of the five-point safety belt; Do not add any lubricant or other chemicals to the cloth cover or the five-point safety belt;


Cleaning instructions for special parts

The shoulder pad and the bassinet cotton pad cover can be removed and washed separately. When washing, please wash by hand when the water temperature is below 40 degrees, and dry it flat. Do not iron, dry clean, and do not expose to the sun.

Product components

Part name


Product pictures are only for reference



Components

A. Stroller frame B. Rear wheel C. Front wheel D. Seat E. Armrest

F. Canopy G. Storage basket



- | | |
|----------------------------|-----------------------|
| 1. Canopy | 7. Rear wheels |
| 2. Front armrest | 8. Folding button |
| 3. Front armrest interface | 9. Handle bar |
| 4. Shoulder pad | 10. Brake device |
| 5. Footrest | 11. Storage basket |
| 6. Front wheels | 12. Folding lock hook |

Unfolding and installation of stroller




Figure 1: Unfolding the frame

1. Open the lock hook 1, then open front frame and push the handle bar as arrow.

Unfolding and installation of stroller




Figure 1: Installing rear wheels

1. Push the axle in until you hear a gentle "click" .

Figure 2: Removing rear wheels

1. Push the button down (1).

2. Pull the wheel (2).




Figure 3: Handle bar height adjustment

1. Press button A.

2. Push forward or backward as needed.

Unfolding and installation of stroller

4




Figure 4: Brake system
1. Press (1), the brake is activated.
2. Press (2), the brake is released.

5




Figure 5-A: Installing the seat
1. Push the seat in until you hear a soft "click" sound.
2. Confirm that the installation is successful.

Figure 5-B: Removing the seat
1. Hold the seat and press the button.
2. Pull out the seat vertically (as indicated by the arrow).

Unfolding and installation of stroller




Figure 5-C: Installing the seat
1. Push in the seat until you hear a soft "click" sound.
2. Confirm that the installation is successful.

Figure 5-D: Removing the seat
1. Hold the seat and press the button.
2. Pull out the seat vertically (as indicated by the arrow).

6






Figure 6: Adjusting the seat reclining angle
The seat has multiple reclining positions, suitable from birth to 15 kg (approximately 3 years old).

Installation and removal of the front armrest

7 Armrest installation



8 Armrest removal



Installation, removal and adjustment of the canopy




Figure 9: Preparing the seat

1. Pull the angle adjustment device to open the seat (1).
2. Install the canopy (2).
3. Install the armrest (until a slight click is heard).
4. Open the canopy.




Figure 10: Adjusting the seat reclining angle

1. Gently pull the angle adjustment device (A) located on the seat back.
2. Adjust the seat position to the desired position.




Figure 11: Canopy adjustment
1. Unfold the canopy.

Figure 12: Unfolding the canopy
1. The unfolded canopy can protect babies from ultraviolet rays and wind, and provide a more comfortable environment.

The use and adjustment of the five-point safety belt




Figure 13-A: Installation of five-point safety belt

1. Put the two insert tongues on the safety belt together (1).
2. Insert the two insert tongues into the "buckle (2)" at the same time.
3. Press down until you hear a soft "click" sound.
4. Ensure safe installation.




Figure 13-B: Removal of the five-point safety belt

1. Press the buttons on both sides of the buckle at the same time.
2. As shown in Figure B, pull the upper part of the five-point safety belt (2).




Figure 13-C: Safety belt length adjustment

1. Hold down the sliding ring and adjust the safety belt.
2. Adjust to the desired position.

Folding of the stroller



Figure 14-1: Folding the stroller (step 1)
1. Retract canopy.



Figure 14-2: Folding the stroller (step 2)
2. Push seat forward.




Figure 14-4: Folding the stroller (step 4)
3. Fold handle forward for storage.




Figure 14-3: Folding the stroller (step 3)
4. Lift up via pull handle.




Figure 14-5: Folding the stroller (step 5)
5. Handle drops automatically during lifting.




Figure 14-6: Folding the stroller (step 6)
6. Stroller fully folded.

Unfolding stroller





Figure 15: Unfolding the stroller

1. Open the lock hook.
2. Raise the handle bar to unfold it.
3. Pull the handle bar to a straight position.



Picture 15: Unfolding the stroller

4. Open the handle bar backwards.
5. Open the seat and adjust the backrest to the desired position.
6. Open the canopy.

Note: Before use, please make sure that all parts are installed safely and correctly, and all locking parts are properly connected.

Footrest adjustment





Figure 16: Adjusting the footrest

1. Press the button (2).
2. Adjust to the desired position.

Adjust canopy height



Picture 17: Adjust canopy height

1. Pull the stroller canopy upwards to adjust the canopy height.
2. Push the stroller canopy downwards to engage the low position.

Technical Support

· For details, please visit www.philips.com/avent